

**ac simulation**

AC1  
Type=log  
Start=0.1Hz  
Stop=10 MHz  
Points=91

Equation

Eqn1  
phase=rad2deg(unwrap(angle(Vout.v)))  
gain=dB(Vout.v)

**dc simulation**

DC1

